

2000i

The Future of Fume Extraction

**3-Phase  
Supply**



# FEATURES

- Clear & informative graphic display
- Highest grade HEPA and carbon technology
- Automatic electronic flow control - maintains a constant extraction rate even as the filter blocks
- Gas and particle sensors to warn the operator
- Adjustable airflow

## SPECIFICATIONS

Voltage	220v	400v
Volume Part Number	0LX2011D	0LX2010D
Vacuum Part Number	022121iD	022120iD
Wattage	3kW	3kW
Frequency	50Hz / 60Hz	50Hz / 60Hz
Cabinet Height	1400mm	1400mm
Cabinet Width	725mm	725mm
Cabinet Depth	726mm	726mm
Cabinet Weight	150kg	150kg
Sound Level	60dBa	60dBa
Airflow	2000m3/h	2000m3/h

## INCLUDED AS STANDARD...

### FILTERS



**Main Filter  
Code**  
110615

**Description**  
HEPA/Chemical



**Pre-filter  
Code**  
111037

**Description**  
F6 Labyrinth

Find out more:



[www.purex.co.uk](http://www.purex.co.uk)



[purex@purex.co.uk](mailto:purex@purex.co.uk)



+44 (0)1405 746030

*Connection kits are available  
see overleaf for options*

# OPTIONS

## Main Filter

<b>Code:</b> 110614 110632 110610	<b>Description:</b> HEPA/Twin Chemical HEPA/Chemical (Cleanroom) Chemical
--	--

## Pre-filter

<b>Code:</b> 111099	<b>Description:</b> F8/F9 Labyrinth
------------------------	--


## Connection Kits

Hose End Diameter


Hose Length

Purex Inlet Diameter

**Code:** 120280    **150mm**    **1.5m**    **150mm**



**Code:** 120287    **100mm**    **3m**    **150mm**



**315mm**    **3m**    **150mm**

### Large Extraction Arm


Our 2m long extraction arm with its triple axis can be used in a variety of applications. The flexibility of the arm allows it to be manoeuvred for all the difficult areas. The arm has a 160mm diameter to reduce restriction and has a large hood of 315mm at the inlet.

- Code:** 840197 - Extraction arm
- Code:** 840198 - Mounting bracket
- Code:** 840199 - 150mm Connection flange
- Code:** 120280 - 150mm Hose kit



*If you do not see a connection kit that fits your machine or pipework, please contact Purex or your representative*

## Interfacing



Interfacing can remotely start the Purex machine when the connected machine starts.

Interfacing can also warn the connected machine when the Purex machine is in alarm.

*Take a look through our Interfacing Guide to see our extensive range of options*



Purex International Limited  
QWP House, Island Drive  
Capitol Park, Thorne  
Doncaster, UK  
DN8 5UE